



TUNING PART

KEY FUNCTION TABLE

LOC	KEY	FUNCTION
SW701	1	TV/VIDEO
SW702	2	CH UP
SW703	3	CH DOWN
SW704	4	VOLUME UP
SW705	5	VOLUME DOWN
SW706	6	FINE TUNING UP
SW707	7	FINE TUNING DOWN
SW708	8	AUTO SEARCH UP
SW709	9	AUTO SEARCH DOWN
SW710	10	CH CALL/PAUSE
SW711	11	PRESET
SW712	12	AF/BAND
SW713	13	SKIP
SW714	14	ANALOG UP
SW715	15	ANALOG DOWN
SW716	16	ANALOG SELECT
SW717	17	SYSTEM

