



Q7T3_LS(FP731-DVI) TROUBLE SHOOTING GUIDE

No Display or display is unstable:


1.1 Interface Board:




**2. BUTTON function:
2.1 Control Board**



3. OSD function:



4. Power Board



5. DVI_BD

DVI No picture or picture unstable

